




# DISH WASH 40

## Safety Data Sheet

SAFETY DATA SHEET
4 in 1 Dishwasher Powder

Product description
So-pure 4 in 1 Dishwash Powder is a powerful but economical product designed to achieve excellent results. Contains a concentrated detergent, glass protection, rinse aid and salt. Certain items are not suitable for automatic dishwashing such as decorated glass, hand-painted porcelain and some plastics - refer to manufacturer's instructions.

Directions
Directions for use: Remove all food scraps before loading dishwasher. Load machine according to manufacturer's instructions allowing adequate space between items. Fill the dispenser to the fill level mark. If your machine has no such mark use 40-50 grams of powder (approx 2 heaped table spoons). Set the machine as normal and commence washing cycle.

Hazards
<p>Corrosive : Causes Burns  R phrases: R34 – Causes burns, R41 – Risk of serious eye damage</p> 
<p>Safety phrases: S2 – Keep out of reach of children, S22 – Do not breath dust, S26 – In case of contact with eyes wash with plenty of water and seek medical advice, S51 – Use in well ventilated areas</p>

PPE Requirements
 

Technical	
Appearance	Granular powder
Colour	White with blue speckles
Odour	Low
Solubility	Freely In Water
Boiling Point	Not applicable
pH(1% Solution)	Prewash > 10.5